

ABBREVIATED SETTING INSTRUCTIONS

MODELS - BZ10** PROXIMITY

Mvmt. Cal. No. W770

FEATURES

- Light Powered
- Perpetual Calendar
- Chronograph
- Power Reserve Indicator
- Bluetooth® 4.0
- Citizen Proximity App
- Time/Date Sync
- Notification and Call Filtering
- Smartphone Search
- Calendar Event Notification

BENEFITS

- Environmentally Clean Energy Source
- Accurate to the year 2100
- 1-Second Chronograph Measures up to 60 Minutes
- Measures Charge Level of Energy Cell
- Free convenient Technical Updates
- Updates across time zones via GSM phone signal
- Notification capable within 10 Meter range of paired device
- Notifications delivered through combination of subtle watch vibrations, second hand indicator, and audio chimes

NOTE: After a complete loss of power or an abnormal function is noticed, an ALL RESET and 0-POSITIONING is required. Be sure to set the time and date after performing these procedures.

NOTE: This watch features a 'power save' function. After 30-minutes of insufficient exposure to light sufficient for charging, the watch enters 'power save' mode and the second hand will stop. Although the second hand is not moving, the correct seconds are stored in memory. Power save mode is automatically canceled when the watch is either exposed to light sufficient for charging or a notification from a connected compatible cellular device is received.

TO CHANGE OPERATING MODES

- Pull the crown out one 'click.'
- Rotate the crown clockwise or counterclockwise so that either side of the mode hand at the 6:00 sub dial indicates the desired operating mode.
- Push the crown in one 'click'. This completes changing operating modes.

ALL RESET AND 0-POSITIONING PROCEDURE

- Pull the crown out one 'click.'
- Rotate the crown clockwise or counterclockwise to set either side of the mode hand at the 6:00 sub dial to the 'CHR' (chronograph) mode.
- Pull the crown out one additional 'click.'
- Press and hold the lower right button (A) for 2 or more seconds, then release. The hands and date will move to their zero positions stored in memory. The correct zero positions are:

Hour, Minute and Second Hands:	12:00
24-Hour Hand (10:00 subdial)	24
Multi-Function Hand (2:00 subdial):	6:00
Date of Month:	Between 31 and 1
- Simultaneously press and hold both the lower right button (A) and upper right button (B) for 4 or more seconds, then release. An alarm tone will sound, the watch will vibrate, and the hands will move indicating a successful all reset.
- Rotate the crown clockwise or counterclockwise to set the date between 31 and 1 with the function hand at the 2:00 sub dial pointing straight down to the 6:00 position.
- Press and release the lower right button (A). The minute and hour hands will rotate slightly indicating they are active for setting.
- Rotate the crown to move the hour and minute hands to the 12:00 position and the 24-hour hand to '24'.

NOTE: The 24-hour hand moves in conjunction with the hour hand and cannot be set independently.

- Press and release the lower right button (A). The second hand will rotate slightly indicating it is active for setting.
- Rotate the crown clockwise to move the second hand to the 12:00 position.

- Push the crown in one 'click'. Rotate the crown clockwise to set the mode hand at the 6:00 sub dial to the 'TME' (time) mode.

- Push the crown in one additional 'click' to the closed position next to the case. This completes the All Reset and 0-Positioning. You must now set the time and perpetual calendar.

TO SET THE TIME AND PERPETUAL CALENDAR

NOTE: If the watch is paired and actively connected with a compatible cellular phone and automatic time updating is enabled on the App, the time and calendar will update without user intervention based on the time and calendar set on the compatible cellular phone. There may be circumstances however that you need to manually set the time.

- Pull the crown out one 'click.'
- Rotate the crown clockwise or counterclockwise to set either side of the mode hand at the 6:00 sub dial to the 'TME' (time) mode.
- Pull the crown out one additional 'click.'
- Press and hold the lower right button (A) for two to three seconds until you see the second hand rotate to the 12:00 position, then release. The function hand at the 2:00 sub dial will rotate slightly and then the minute hand will rotate indicating the time may be set.
- Rotate the crown clockwise or counterclockwise to set the time. Be sure to pay attention to the 24-hour hand at the 10:00 sub dial to ensure the proper AM or PM time is set.
- Press and release the lower right button (A). The function hand at the 2:00 sub dial will rotate indicating the date of month may be set.
- Rotate the crown clockwise or counterclockwise to set the current date of month. **Note:** The function hand makes 5 rotations for each date change.
- Press and release the lower right button (A). The second hand will rotate to indicate the month and leap year settings stored in memory.
- Rotate the crown clockwise to set the current month and leap year. Each hour indice represents the month, while the hour indice and the 3 minute indices immediately following the hour indice indicate the leap year or years past a leap year.

Month of Year



Leap Year Setting



- Press and release the lower right button (A). The multi-function hand at the 2:00 sub dial will rotate indicating the day of week may be set.
- Rotate the crown clockwise to set the day of week.



- Press and release the lower right button (A). The hour and minute hands will rotate slightly indicating they are active for setting.

- Rotate the crown clockwise to correct for the minutes elapsed during the setting process.

- Press the crown in two 'clicks'. This completes setting the time and perpetual calendar.

TO SET THE LOCAL (SECONDARY) TIME

- Pull the crown out one 'click.'
- Rotate the crown clockwise or counterclockwise to set either side of the mode hand at the 6:00 sub dial to the 'L-TM' (local/secondary time) mode.
- Pull the crown out one additional 'click.'
- Rotate the crown clockwise or counterclockwise to set the time in 15-minute increments. Be sure to pay attention to the 24-hour hand at the 10:00 sub dial to ensure the proper AM or PM time is set.
- Push the crown in two 'clicks.'

TO USE THE ALARM

NOTE: Once set and activated (turned 'on'), the alarm will sound once per day for up to 15 seconds. The alarm will sound at the same time each day unless deactivated (turned 'off').

- Pull the crown out one 'click.'
- Rotate the crown clockwise or counterclockwise to set either side of the mode hand at the 6:00 sub dial to the 'ALM' (alarm) mode.
- Pull the crown out one additional 'click.' The second hand will rotate to the 12:00 position, the function hand at the 2:00 sub dial will rotate to indicate the alarm 'on' or 'off' setting and the hour and minute hands will rotate to indicate the alarm time set in memory.
- Press and release the lower right button (A) to turn the alarm 'ON' or 'OFF'.
- Press and hold the lower right button (A) for two to three seconds until you see the minute hand rotate, then release.
- Rotate the crown clockwise or counterclockwise to set the desired alarm time. Be sure to pay attention to the 24-hour hand at the 10:00 sub dial to set the proper AM or PM time.
- Push the crown in one 'click.'
- Rotate the crown clockwise to set the mode hand at the 6:00 sub dial to the 'TME' (time) mode.
- Push the crown in one additional click. This completes setting the alarm.
- When the set alarm time is reached, the alarm will tone until one of the buttons is pressed and released or for a maximum of 15 seconds.

For complete operating and compatible cellular phone pairing and use instructions, please refer to the W770 movement instruction guide found in the setting instruction section under the support link of our website at

www.citizenwatch.com/en-us/support/setting-instructions/